

## Azteca DIY Chips



### Ingredients

Azteca Tortillas

Salt to taste

Cooking spray (or oil)

### Directions

Preheat oven to 375° F.

Cut each tortilla into 6 or 8 wedges.

Place wedges, in a single layer, on baking sheets. Spray wedges with cooking spray.

Bake 5-7 minutes or until wedges are light brown and crisp.

Remove chips to a wire rack to cool.

Place chips on serving plate. Serve immediately.