

Turkey Cranberry Wraps



Remove tortillas from refrigerator; set aside. Let stand at room temperature for 10-15 minutes or until soft and flexible.

Divide turkey and stuffing and place on tortillas. Top with approximately 2 tablespoons cranberries. Fold or roll up to enclose filling.

Ingredients

1 package Azteca® Flour Tortillas

2 cups diced or shredded cooked turkey

2 cups prepared bread stuffing

1 can whole cranberries

Directions

Remove tortillas from refrigerator; set aside. Let stand at room temperature for 10-15 minutes or until soft and flexible.

Divide turkey and stuffing and place on tortillas. Top with approximately 2 tablespoons cranberries. Fold or roll up to enclose filling.